


1. NEW/EXISTING PARAPET WALL.
2. 2X PT WOOD NAILER. ANCHOR SECURELY TO PARAPET WALL WITH SPECIFIED FASTENERS.
3. RE-ROOFING: INSTALL NEW 5/8-INCH PLYWOOD TO ALL PARAPET WALLS. ANCHOR SECURELY WITH SPECIFIED FASTENERS.
3. NEW CONSTRUCTION: INSTALL BASE FLASHING DIRECTLY TO PARAPET WALL.
4. 1X PT WOOD NAILER (SPACER). ANCHOR SECURELY
5. 3/4-INCH PT PLYWOOD. CHAMFER CORNERS AS SHOWN. INSTALL TO SLOPE TOWARDS ROOF.
6. 2-PLY WALL (BASE) FLASHING SYSTEM. CONTINUE SMOOTH PLY MEMBRANE OVER TOP OF WALL, TYPICAL.
7. CONTINUOUS 0.063-INCH ALUMINUM COPING CLEAT. ANCHOR SECURELY TO NAILER WITH SPECIFIED FASTENERS 6-INCHES O.C.
8. CONTINUOUS SHEET OF 45 MIL EPDM. SEAL ALL LAPS WITH SPECIFIED ADHESIVE OR SEAM TAPE. EXTEND EPDM TO COVER ALL WOOD AND DOWN ROOF SIDE TO EXPOSE 2-INCHES (MINIMUM). ALTERNATE: AN APPROVED 40 MIL PEEL 'N' STICK MEMBRANE MAY ALSO BE USED.
9. CONTINUOUS 0.050-INCH ALUM. COPING CAP. SHOP FABRICATE ALL TRANSITIONS, CORNERS AND BENDS 24" FROM EDGE. SOLDER SOLID (HELIARC) ALL JOINTS. ENGAGE SECURELY TO COPING CLEAT AND FASTEN 12-INCHES O.C. IN SLOTTED HOLES. PROVIDE 3-INCH WIDE 0.040-INCH ALUM. DRIVE CLEATS AT LAPS. TURN DOWN DRIVE CLEAT TO COVER FACE OF COPING AND CRIMP METAL TO ENGAGE DRIP EDGE (BOTH SIDES).



TYPICAL LAP CONDITION
FOR DRIVE CLEATS

TITLE: TYPICAL PARAPET WALL COPING DETAIL

SPEC. SECTION: 07-60-00.05 APPENDIX E

DATE: 07/11/2019